Bow-it-All by Zutter Innovative Products Product Information Tips



Bow-it-All Board

The Bow-it-All foam/EVA board may reveal markings or dents caused by pressure from the retail packaging. These are not considered defects. These indentations will go away by allowing the board to air out and "stretch" once out of the packaging. In some cases they will go away rather quickly. In other cases it may take a bit longer.

Locking Pegs (Vertical Placement)

It may be possible that the pegs when first installed (or anytime after) the pegs may not appear 100% vertical on the metal plate. This can be modified by manually adding pressure to the peg to correct it to its proper position.

Wrench Storage Compartment

At times, the wrench may slip from the storage compartment. If this occurs, very lightly apply pressure on the wrench to achieve a *very* light bend. This minimal bend on the wrench will create a tighter fit into the storage channel. **Caution** - the bend should be *very* minimal. Excessive bend on the wrench will cause it to fit too tightly into the storage channel.

Peg Storage

Not all pegs will fit in the storage channels with the same tightness. Some may fit with a slight tightness, others may appear slightly loose. When all pegs are stored in their corresponding channels and the board is placed in its tote, the board and pegs will be securely stored.

Metal Pegs

In some cases, the nut on the peg will come loose. This can be resolved by tightening the nut on the peg to maximum tightness and then dropping a tiny drop of crazy glue onto the peg from the top of the nut.

Ribbon Spool Holding Pegs

The ribbon spool holding pegs do not include a tightening nut, as the looser fit allows free flow of ribbon from the spools. It may appear that there is too much "give" on these pegs, however this is considered normal and serve the aforementioned purpose.

